



## Spartan Chemical Company, Inc.

1110 Spartan Drive, Maumee OH 43537

Phone: (800) 537-8990

www.spartanchemical.com

### Training Information

**Market Segment:**

Building Service Contractors, Education, Food Processing\_Agricultural, General Manufacturing, Government, Healthcare, Lodging\_Hospitality, Other, Retail

**Title:**

#### HOW TO RECOAT A FLOOR

Check If Applicable:  Rx Procedure  None  
 Cleancheck Procedure

**Tools & Materials Needed:**

- A. Bucket with wringer
- B. Liner
- C. Finish mop
- D. "Wet floor" signs Gloves and goggles

**Procedures:**

I. Purpose of Recoating the Floor

- A. Bring gloss level back.
- B. Restore finish layer worn away through:
  - 1. Foot traffic
  - 2. Top scrubbing

II. Procedure for Recoating a Floor

- A. Start with a top scrubbed floor. Allow floor to dry.
- B. Put or keep "Wet floor" signs at all entrances.
- C. Put on gloves and goggles.
- D. Pour finish into liner in mop bucket.
- E. Dip finish mop into floor finish. Wring out just to point that it is not dripping.
- F. Start at furthest corner from door.
  - 1. Frame a small area and fill in using a figure eight pattern.
  - 2. Turn mop frequently.

3. Apply finish all the way to the baseboard.
  4. Work backwards toward the door.
- G. Continue working side by side areas, keeping overlapping edges wet.
- H. Allow finish to dry thoroughly.
- I. Clean up.
1. Wash out finish mop, hang to dry.
  2. Throw away leftover finish and liner. Twist, tie and toss.
  3. Clean all equipment and store for future use.