



Spartan Chemical Company, Inc.

1110 Spartan Drive, Maumee OH 43537

Phone: (800) 537-8990

www.spartanchemical.com

Training Information

Market Segment:

Building Service Contractors, Education, Food Processing_Agricultural, General Manufacturing, Government, Healthcare, Lodging_Hospitality, Other, Retail

Title:

PROCEDURE FOR STRIPPING SLATE

Check If Applicable: Rx Procedure None
 Cleancheck Procedure

Tools & Materials Needed:

1. Slate stripper
2. Machine and brush
3. Wet/dry vacuum
4. A hand scrub brush
5. Gym mops
6. Two mop buckets and wringers
7. Rags
8. Gloves and personal protective equipment.
9. Wet Floor signs

Procedures:

Slate floors are hard to clean or strip. Slate has a natural groove to the surface. As you mop, all liquids settle in the grooves.

PROCEDURE:

Put on personal protective equipment.

1. Mix stripper in hot water and follow manufacturer's recommendations.
2. Section floor in 10' x 10' area to be stripped.
4. Scrub floor with a machine equipped with a brush.
5. Pick up scrub solution with wet/dry vacuum.
6. Apply one clear water rinse to the area you have just cleaned.
7. Wipe baseboards with a damp rag.
8. Repeat procedure until entire area is stripped.
9. Rinse entire area two more times.
10. Apply first coat of sealer.