



Spartan Chemical Company, Inc.

1110 Spartan Drive, Maumee OH 43537

Phone: (800) 537-8990

www.spartanchemical.com

Training Information

Market Segment:

Healthcare, Other

Title:

HOW TO CLEAN AN OPERATING ROOM SUITE

Check If Applicable: Rx Procedure None
 Cleancheck Procedure

Tools & Materials Needed:

- A. Two buckets with wringers
- B. Wet mop and handle
- C. Clean cloths
- D. Trigger spray bottle
- E. Dust mop, handle and frame
- F. Dust pan and broom
- G. Bowl swab
- H. Toilet tissues and paper towels
- I. Biohazard bags
- J. "Wet floor" signs
- K. Gloves and personal protection equipment

Products:

- 1. Cleaner disinfectant
- 2. Glass cleaner
- 3. Bowl cleanse
- 4. Dust mop/dust cloth treatment

Procedures:

I. Purpose of Cleaning the Operating Room Suite

- A. Prevent the spread of nosocomial infections by removing gross contamination and disinfecting all surfaces.
- B. Improve worker safety by providing a sanitary work area.

II. Procedures for Cleaning an Operating Room Suite

- A. Put on gloves and other personal protection equipment. Follow the Bloodborne Pathogen Standard.
- B. Damp dust OR central supply rooms including shelves, cabinets, furniture, window sills, suction machines, and all other equipment with disinfectant cleaner in a trigger sprayer and a clean cloth.
- C. Clean dressing rooms and bathrooms, including furniture and mirror sills with a disinfectant cleaner. Clean the commode with bowl swab and the bowl cleanse product. Refill paper towels and toilet tissue dispensers.

- D. Using a disinfectant cleaner in a trigger sprayer, clean, or damp dust, work rooms, work tables, sinks, shelves and all furniture.
- E. Empty clothes hamper and clean with the disinfectant. Replace plastic liner. Transport linens to the Soiled Pick-up Room. Use biohazard bags as required.
- F. Remove the liner in the wastebasket; twist tie it closed. Wipe the wastebasket inside and out with the cleaner disinfectant. Replace liner with a new one.
- G. Clean all scrub sinks with the disinfectant.
- H. Spray the dust mop with dust mop/dust cloth treatment. Dust the floor with the treated dust mop. Pick up the soil with the dust pan and broom.
- I. Place the "Wet floor" signs. Follow the double bucket method as described in "How to Wet Mop/Disinfect Floors" to clean and disinfect the floor.
- J. Change back into street wear before leaving the Operating Room Suite.